


# 500S "Classic" Schematic Layout

*Schematic for the 500S Burnout Oven with Classic Control and Triac Assembly*



Wiring Diagram  
 Revised 10-2000  
 Dwg by: the WD

The DLS Corporation shall not be liable for any damage or injury due to repair or installation of parts by non-DLS personnel. For questions or comments, please contact your dealer or DLS Corporation at 1-800-514-7063. Revised 9-23-05.



DLS Corporation  
 246 West Taft Ave  
 Orange, CA-USA 92865